

## GP Universal 12

### Installation Instructions:

1. Before the installation can begin, it is important to examine the surface that will be covered with artificial grass to ensure that:
  - all surfaces are sufficiently flat and stable.
  - all necessary improvements to the subsoil have been executed.
2. Roll out the first roll of artificial grass, ensure it placed in the right direction and then mark where the other rolls will be installed.
3. Check the desired width of the rolls.
4. Roll out the next roll of artificial grass next to the previous one, and then determine the placement for all additional rolls.
5. Make the seam between two rolls with a carpet knife. *Please note*, both rolls need a clean cut in order to make a smooth joint.
6. Prepare the adhesion of the surface / seams with strong artificial grass or professional broadloom carpet adhesive. The width of the seams between 2 rolls should not be more than 3 mm.
7. Fold out the sides of both rolls to create an opening of 60 cm to 75 cm.
8. At this point, the first rolls are ready for adhesion. Put the adhesive on the concrete floor and spread it evenly with an adhesive comb. The quantity of the adhesive is determined by the teeth of the adhesive comb, but it needs to be  $\pm 3$  mm thick and 15 to 20 cm wide.
9. Carefully press the back of the artificial grass on to the adhesive by hand. Make sure that it has been pressed well on to the adhesive in order to create a tight bond. Pressing or lightly rolling on top of the grass afterwards guarantees a good adhesion.
10. Repeat steps 3 - 8 until your artificial grass surface has been installed completely.
11. If all the artificial grass has been installed, check all seams once more and apply more adhesive if necessary.
12. Cut the outline of the artificial grass in the desired form.
13. Remove all rest material of the artificial grass with a broom.