

## **Installation Guide for Indoor Application**

1. Before the installation can begin, please check the surface area:
  - All surfaces must be sufficiently flat and stable.
  - All necessary improvements to the subsoil have been executed.
2. When the area has achieved the requirements above, unroll the first roll of artificial grass and put it into place. Then create marks where the other rolls will need to be installed.
3. Check the desired width of the rolls to ensure you will be able to cover the area efficiently.
4. Unroll the next roll of artificial grass, and line it up next to the previous one. This will help you determine the place for the additional rolls.
5. Make a seam between two rolls with a carpet knife. Please note, both rolls need to have a clean cut for them to create a smooth joint.
6. Prepare the adhesion of the surface / seams with strong artificial grass or professional broadloom carpet adhesive. (The width of the seams between two rolls cannot be more than 3 mm)
7. Fold out the sides of both rolls, so there is an opening of 60 to 75 cm.
8. At this point, the first rolls are ready for adhesion. Put the adhesive on the concrete floor and spread it equally with an adhesive comb. The quantity of the adhesive is determined by the teeth of the adhesive comb. However, it needs to be  $\pm 3$  mm thick and 15 to 20 cm wide.
9. Carefully press the back of the artificial grass onto the adhesive by hand ensuring that it has been pressed well. Pressing or lightly rolling afterwards guarantees a good adhesion.
10. Repeat steps 3 - 8 until your artificial grass surface has been installed completely.
11. Once all the artificial grass has been installed, perform a final check on all the seams and apply more adhesive if necessary.
12. Cut the outline of the artificial grass in the desired form.
13. Remove any excess material with a broom.